4kW, 230V Frost Protection Controllers

#### **CONTACT US:**

- © 0044 (0) 1704-516 501
- www.united-automation.com



#### **KEY FEATURES:**

- Simple Setup & Installation: Easy to install, making it ideal for both new setups and retrofits.
- 2m Long Sensor Included: Comes with a built-in encapsulated sensor, ensuring accurate temperature monitoring.
- Soft Start Function: Gradual switch-on to protect your heating elements.
- Wide Temperature Range: Available in -10°C to 10°C or 0°C to 20°C options, making it versatile for different environments.
- **Solid State Reliability:** Durable and maintenance-free, ensuring long-term, worry-free operation.
- **IP65 Ingress Protection:** Robust design with high-level protection against dust and
- **High Current Capacity:** Capable of handling up to 20A, suitable for demanding applications.

### **APPLICATIONS:**

- **Frost Protection for** Pipework: Ideal for protecting pipes in outdoor or unheated environments.
- **Heater Tape Control:** Ensures efficient operation of heater tapes to prevent freezing.
- Infra-Red Quartz Lamp Control: Perfect for maintaining optimal temperatures in various settings.

Introducing the ENVIROSTAT FP4E & FP4i Electronic Thermostats—vour ultimate solution for energy-efficient frost protection. Designed specifically for pipework where thermal insulation alone falls short, these advanced thermostats ensure your pipes remain protected from freezing and ice damage. Ideal for controlling heater tape or Infra-Red (IR) quartz lamps, the ENVIROSTAT FP4 series offers two robust models to suit your needs:

- FP4E: A straightforward, reliable thermostat offering 4kW frost protection with simple temperature control functions.
- FP4i: An enhanced version with additional alarm features for comprehensive protection and monitoring.

## **TECHNICAL SPECIFICATIONS**

(All models unless otherwise stated)		
Supply voltage	230V ac +/- 10%	
Supply frequency	50Hz	
Power switching capacity	4kW max.	
Load current	20A max.	
Temperature range	-10-10°C OR 0-20°C	
Temperature accuracy	1°C	
Current consumption	15mA	
Soft start duration	1 second	
Output and load fault detection	Only on FP4i model	
Power and status LED indicators	Only on FP4i model	
Supply terminal connections	0.2 to 6mm² rising clamp	
Gland cable entry	8mm Ø (Note: cable MUST be round to ensure IP rating)	
Ambient operating temperature	-20-40°C	
Ingress protection (IP) rating	IP65	
Built-in sensor	Encapsulated 10kΩ NTC thermistor probe, 2m long	
Sensor monitoring	FP4E: open or short circuit - unit shuts down FP4i: open or short circuit - unit shuts down and alarms	
Sensor terminal connections	0.1 to 1.5mm <sup>2</sup> Rising clamp	
Senor mounting	To secure to pipe etc., use appropriately sized nylon cable ties	
Dimensions		
Enclosure dimensions	95(W) x 130(L) x 55(H)	
Fixing holes and centres	4 x 4.8mm Ø holes on fixing centres 97(W) x 82(L)mm	

#### YOU MUST READ THIS BEFORE INSTALLATION



**ELECTRICAL SAFETY** 

WARNING: RISK OF ELECTRIC SHOCK Always consult the Installation & Maintenance Instructions before connecting this product to the power supply. **WARNING: Disconnect Power Before Servicing** Ensure the electrical supply is safely disconnected before connecting to any supply, load, or control terminals



INSTALLATION REQUIREMENTS

INSTALLATION REQUIRE
WARNING: Installation by Qualified Personnel Only

This product must only be installed or fitted by a competent, qualified installer familiar with the relevant electrical standards and installation practices.



USER RESTRICTIONS

WARNING: Not for Use by Vulnerable Individuals This product is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and by a person responsible for their safety.




USAGE ENVIRONMENT

WARNING: Industrial Use Only This is an industrial-grade product and is not intended for household



HOT SURFACE WARNING

WARNING: Hot Surfaces On certain models, surfaces marked with this symbol become hot during use. Avoid direct contact and follow all





4kW, 230v Frost Protection Controllers

# **Product Setup**

## **Connecting the System:**

- Use the appropriate round-section cable to connect the mains supply and load to the controller.
- Position the sensor in the desired location to measure air temperature or secure it to a pipe using cable ties for direct temperature monitoring.

# **Operation**

## **Setting the Temperature:**

Adjust the set point temperature using the main knob.

## **Automatic Temperature Control:**

- When the ambient temperature falls below the set point, the load output initiates a soft start for 1 second before the main output relay activates. During this time, the output LED will light up, indicating that the system is active.
- As the ambient temperature rises to or exceeds the set point, the load output switches off, and the output LED will turn off, signalling that the system is idle.

# Alarms (FP4i Model Only):

- The FP4i model includes advanced fault detection features:
  - o **Sensor Monitoring:** Detects open-circuit or short-circuit temperature
  - o **Periodic Output Testing:** The unit automatically tests the output at power-up and every four hours. The output may momentarily switch off during these tests, resuming normal operation afterwards.

#### **Fault Detection:**

- Open-circuit/short-circuit temperature sensor.
- Open-circuit load.
- Short-circuit or open-circuit in the semiconductor device or relay.

#### **Alarm Indications:**

- The alarm LED will flash to indicate faults:
  - Sensor Alarm: Fast flash rate (approximately 0.1 seconds).
  - Output/Load Alarm: Slower flash rate (approximately 0.5 seconds).






4kW, 230v

**Frost Protection Controllers** 

# **INSTALLATION**

# Mounting:

• Use the provided fixing-hole template to securely mount the enclosure to the wall. Ensure the unit is installed in the correct vertical position to maintain its IP rating.





**3** 0044 (0) 1704-516 501












4kW, 230v

**Frost Protection Controllers** 

## Wiring:

Follow the wiring diagram provided to make the correct connections and ensure cable entry points are secure. Tighten the cable glands to maintain the unit's IP rating. The set point control dial is also illustrated for easy reference.



## **RECOMMENDATION FUSING**

It is recommended to use standard F-type quick-blow fuse or circuit breaker (MCB 'type 'B'- rated at 20A Max.) for 'in line' unit protection. (See the SRA Datasheet for further information).

### **DOCUMENTS**

Other documents, which may be appropriate for your applications, are available on request.

Code	Identity	Description
X10255	SRA	Safety requirements: Addressing the Low Voltage Directive (LVD) including Thermal data/Cooling, Live parts warning, Earthing requirements & Fusing recommendations
P01.1	COS	UAL Conditions of Sale

NOTE: It is recommended that installation and maintenance of this equipment should be carried out by suitably qualified personnel, with reference to the current edition of the I.E.T. Wiring Regulations BS7671. The regulations contain important requirements regarding the safety of electrical equipment.

## PRODUCT CODE AND RELATED PRODUCT CODE

Product Code	Product Description
A87350	Envirostat FP4E 4kW 230V - Frost Protection Controllers
A87351	Envirostat FP4i 4kW 230V - Frost Protection Controllers

Note: For alternative voltage requirements or alternative options please contact us directly



BMF House - Wight Moss Way, Southport Business Park Southport PR8 4HQ ENGLAND, UNITED KINGDOM Contact Us:

① 0044 (0) 1704-516 501

 □ enquiries@united-automation.com www.united-automation.com







