X20106 - Infresco CT 4KW **User Manual** Issue 4





Contents

| 1 | | / Features | |
|----|------|---|-----|
| 2 | Ted | chnical Specification | . 2 |
| 3 | Inti | roduction | . 3 |
| 4 | Ins | tallation | . 3 |
| 5 | Wi | ring | . 3 |
| 6 | Cor | mmissioning | .3 |
| 7 | Мо | ounting Template | . 3 |
| 8 | Wi | ring Diagram | . 4 |
| 9 | Red | commendations & Safety Requirements | . 5 |
| | 9.1 | Supporting Datasheets for products and applications | . 5 |
| | 9.2 | Safety Note | . 5 |
| | 9.3 | Electrostatic Discharge (ESD) | . 5 |
| 10 | | Product Applications | 6 |

UNITED AUTOMATION LTD



Southport Business Park Wight Moss Way Southport, PR8 4HQ **ENGLAND**

Tel: 0044 (0) 1704 - 516500 enquiries@united-automation.com www.united-automation.com **∳**@∂unitedautomationltd **᠑**UA_Limited











Page 1 of 6 Issue: 4 Date: 14, June 2023

X20106 - Infresco CT 4KW **User Manual** Issue 4





Key Features 1

- Energy saving provides heat for a pre-determined time period.
- Extends Lamp Life.
- Soft-start/zero-voltage switch-off
- Low-cost
- Easy to install
- Power ON (Blue) & Heater ON (Red) LED indication.

Technical Specification 2


| Supply Voltage | 230VAC +/- 10% 50/60Hz | |
|---------------------------------------|------------------------------------|--|
| Switching Capacity | 4kW Max. | |
| Lamp On-Time | 1 to 60 Minutes | |
| Current Consumption (control circuit) | 50mA | |
| Terminals | 2.5mm ² Rising Clamp | |
| Operating Temperature | -20 to 40°C | |
| Protection Rating | IP65 | |
| Gland Diameter | Max Cable Entry 2.5mm ² | |
| Enclosure Dimensions (mm) | 120 x 90 x 50 (W x L x H) | |

UNITED AUTOMATION LTD

automation

Southport Business Park Wight Moss Way Southport, PR8 4HQ **ENGLAND**

Tel: 0044 (0) 1704 - 516500 enquiries@united-automation.com www.united-automation.com **f @ d** unitedautomationItd **♥** UA_Limited







Page 2 of 6 Issue: 4 Date: 14, June 2023





X20106 - Infresco CT 4KW

User Manual

Issue 4

3 Introduction



The Infresco-T 4kW is part of a family of controllers designed to provide energy saving when used with Quartz Infrared Halogen Lamps or other Heating and Lighting Products. The 'T' model switches the lamps on for a pre-determined time period of between 1 and 40 minutes.

The microcontroller-based unit incorporates zero-voltage switching and a soft-start function to eliminate the lamps' initial high inrush current – potentially increasing lamp life by as much as 30%. Installation of the unit is simple and once installed is relatively maintenance-free.

4 Installation

Important: Carefully read the following information before installing the unit.

The Infresco-T 4kW should be fixed securely using the four mounting holes accessible from the front of the unit. Remove the lid to access the mounting holes. To ease installation, a mounting template is provided on the next page to locate the 4 mounting hole centres.

IMPORTANT! The unit must be orientated with the cable glands facing down.

5 Wiring

It is recommended that installation and maintenance of this equipment should be done with reference to the current edition of the I.E.E. wiring regulations (BS7671) by suitably qualified/trained personnel. These regulations contain important requirements regarding safety of electrical equipment (for International Standards refer to I.E.C/ directive IEC950).

Warning! Isolate the mains supply before commencing any work on this unit. Ensure all earth wires are connected to maintain earth continuity to the lamp fittings.

The unit is fitted with two cable glands. Only one cable should be fitted per gland to prevent degrading the unit's IP rating. When fitting two lamps, refer to 'Wiring Diagram' for an alternative wiring configuration using a junction box.

The mains supply connects to the terminal block marked 'LINE'. Connect the supply LIVE to the 'L' terminal, NEUTRAL to the 'N' terminal and EARTH to the 'E' terminal.


The lamps connect to the terminal block marked 'LOAD'. Connect the load LIVE to the 'L' terminal, NEUTRAL to the 'N' terminal and EARTH to the 'E' terminal. If two lamps are to be fitted, they must be wired in parallel.

Check all wiring and make sure the cable glands are tightened.

6 Commissioning

Set the on-time pre-set (VR1) to a time period of between 1 and 40 minutes. VR1 is located at the top of the printed circuit board as shown above. Replace the lid and switch on the mains supply to the unit. Press the push-button on the front of the unit to switch the lamps on.

7 Mounting Template




UNITED AUTOMATION LTD



Southport Business Park Wight Moss Way Southport, PR8 4HQ ENGLAND

Tel: 0044 (0) 1704 – 516500 enquiries@united-automation.com www.united-automation.com












Page 3 of 6 Issue: 4 Date: 14, June 2023

X20106 - Infresco CT 4KW **User Manual**

Issue 4

Wiring Diagram






UNITED AUTOMATION LTD

automation

Southport Business Park Wight Moss Way Southport, PR8 4HQ **ENGLAND**

Tel: 0044 (0) 1704 - 516500 enquiries@united-automation.com www.united-automation.com







Page 4 of 6 Issue: 4 Date: 14, June 2023







X20106 - Infresco CT 4KW

User Manual

Issue 4



9 Recommendations & Safety Requirements

9.1 Supporting Datasheets for products and applications

Other documents, which may be appropriate for your applications, are available upon request.

| Code | Identity | Description |
|--------|----------|---|
| X10255 | SRA | Safety requirements: Addressing the Low Voltage Directive (LVD) including Thermal Data/Cooling, Live parts warning, |
| | | Earthing requirements and fusing recommendations |
| | DoC | Declaration of conformity (relating to purchase order) |
| P01.1 | COS | UAL Conditions of Sale |

9.2 Safety Note

It is recommended that installation and maintenance of this equipment should be carried out by suitably qualified personnel, with reference to the current edition of the I.E.T. Wiring Regulations BS7671. The regulations contain important requirements regarding the safety of electrical equipment.

9.3 Electrostatic Discharge (ESD)

This product range has been identified has requiring protection from electrostatic discharge (ESD). They include integrated circuits (IC's) that may be damaged or degraded if mishandled. They are much less vulnerable when built in-circuit and suitable and sufficient precautions are taken when being handled.

To address this matter, when the products are sold separately, they are protected in an ANTI-STATIC polyethylene bag. Appropriate care should be taken when handling the units for installation.

Further supporting data is available on request or on our website: SWP05-06 - A guide to ESD




Not for general waste

UNITED AUTOMATION LTD

united

Southport Business Park Wight Moss Way Southport, PR8 4HQ ENGLAND Tel: 0044 (0) 1704 – 516500 enquiries@united-automation.com
www.united-automation.com









Page 5 of 6 Issue: 4 Date: 14, June 2023

X20106 - Infresco CT 4KW

User Manual

Issue 4

10 Product Applications

A few examples of typical applications are as follows:

- Patio areas
- **Smoking shelters**
- Restaurants
- Warehouses
- Workshops
- Garden lighting





united automation

Southport Business Park Wight Moss Way Southport, PR8 4HQ **ENGLAND**

Tel: 0044 (0) 1704 - 516500 enquiries@united-automation.com www.united-automation.com **f @ d** unitedautomationItd **♥** UA_Limited









Page 6 of 6 Issue: 4 Date: 14, June 2023